

Assembly Instructions for 1m trough x 240mm wide x 350mm high with 8x2 ends



Just follow the same procedure for higher troughs

Visit [www.gardenlarch.co.uk](http://www.gardenlarch.co.uk)

Tel Chris 07988179838

<ul style="list-style-type: none"> <li>• Unpack the trough. This is the components for 1 x 1 m trough.</li> <li>• Trough ends 8x2</li> <li>• 16 x 2 inch screws</li> <li>• 2 x 1m planed boards</li> <li>• 2 x 1m planed boards with rail attached.</li> <li>• Bottom slats</li> </ul> <p><b>Tools:</b> we advise you use Cordless drill / screwdriver with Philips head attachment Or Philips type screwdriver</p>	
<p>1. Align the 2 ends approx 1m apart and place the 1m planed board on top. Make sure that the board is squarely lined up with the top of the 8x2 ends. Now attach with the 2 inch screws through the pre drilled hole.</p>	
<p>2. Attach the bottom 1m board with the rail on. Now turn over the semi assembled trough and repeat the process.</p>	
<p>3. The trough is now ready just place the bottom slats on top of the rail. If the slats appear too long for the trough, just place one on top of the other to give the correct length. You can either fill with soil /compost directly, or use a liner if you wish to retain moisture for longer.</p> <p><b>I hope this assembly guide has helped. We hope you enjoy your trough for years to come! Happy growing !!</b></p>	

