

Workbench Assembly

Please Read Before Assembly!!

Visit www.gardenlarch.co.uk

Chris - 07988179838



components

1. 2x end boards & legs (assembled)
2. 2x 6x1 x1.5m side boards drilled at 2 inch from ends & 2 holes @ 750mm for 4x2 cross supports
3. 4x 6x1x1.5m drilled at 2 inch from the ends . These are the top boards.
4. 2x 6x1 x1.5m drilled at 5.5 inch from the ends – bottom boards.
5. 1x 4x2 x 500mm – middle support

1. Lay the 2 end boards with legs approx 1.5m apart. Make sure that the planed end boards are facing outwards.



2. Then take the side boards and attach to the 2 end boards and legs.



3. With the side boards attached, place the table upright, and secure the 4x2 support , lining up the 2 pre drilled holes.

Next attach the bottom boards



Now attach the 4 top boards – they are planed, You can either position them so they have an equal overhang, or have the overhang all on one side if the bench is going up against a wall.

These have 2 holes drilled 2 inch from the ends and one at 750mm in the middle. – That's it the workbench is complete. Hope you enjoy using it.



The finished work bench – I hope this guide has been helpful