

GARDEN LARCH

Raised Beds, Planters, Troughs & Tables

21mm Top Workbench Assembly Instructions



Components

- 2 leg sections (pre-assembled).
- 2 142 x 21mm side boards with 2 holes drilled for the 95 x 45mm support.
- 4 top boards.
- 3 bottom boards, these will be the shorter boards.
- 1 95 x 45mm x 500mm – middle support.
- Fixings:
36 x 60mm screws and 12 x 50mm screws (bottom boards).

Recommended Tools

Cordless drill with poz 2 fitting.

1. Lay the legs apart on a flat surface.
Make sure that the planed end boards are facing outwards.
2. Place the side board on top of the legs. The 2 holes drilled in the board need to be placed to the top. Make sure that the board is aligned squarely to the edge of the leg. And attach both ends with the 60mm screws.
3. Turn the legs over and repeat the process.
4. Attach the shorter bottom boards. Use the 50mm screws.
Make sure that the boards are squarely aligned.
5. With the side boards attached, place the table upright and secure the 95 x 45mm support, lining up the 2 pre drilled holes.
6. The 95 x 45mm support is attached with the 95mm side facing upwards
7. With the workbench carcass in the upright position it is now time to fix the top boards. Use the 60mm screws. Align the boards in the desired position and fix the top boards at the ends and middle.

The finished workbench



Jan 2018

www.gardenlarch.co.uk

Chris: 07988 179838

e-mail: sales@gardenlarch.co.uk

Phil: 07778 547900